

UZ [Nominal diameter] / [Pressure] AC

/ [Flow direction] / [Gas type]

1. Specifications

_	-	_	_	-		_	-		
	(•	1	N	1	o	d	е	I

UZ [Nominal diameter] / [Pressure] AC / [Flow direction] / [Gas type]

Nominal diameter	Pressure	Flow direction	Gas type
□ 40	0 (Type without pressure sensor)	□ L (left to right)	□ 13A (city gas 13A)
□ 50	\Box 500 (Type with pressure sensor)	□ R (right to left)	🗆 PRO (propane)
		D (Downward)	🗆 BTN (butane)
		🗆 U (Upward)	□ N2 (nitrogen)
			□ AR (argon)

Model

Connection diameter

Model UZ40		UZ50
Connection diameter	JIS10K 40A flange	JIS10K 50A flange

Flow range (Actual flow)

Flo	ow range (Actual flow) [m ³ /h]						
	Model	UZ40	UZ50				
	Gas type	13A, PRO, BTN, N2, AR	13A, N2, AR	PRO, BTN			
	Flow range	+1.6 to 80	+3.0 to 150	+3.0 to 80			

Accuracy

Flow measurement accuracy (Actual flow)

1 10 11 111	ououronnonn uo			[, /]
Model		UZ40	UZ50	
Gas type		13A, PRO, BTN, N2, AR	13A, N2, AR	PRO, BTN
Accuracy	±0.5%FS	+1.6 to 8.0	+3.0 to 15.0	
	±1.0%FS			+3.0 to 15.0
Ac	±4.0%RD*	+8.0 to 80	+15.0 to 150	+15.0 to 80

* In case a distance from an elbow of minimum 10D in the upstream side and 5D in the downstream side of the meter can be secured: ±2.0%RD

Conversion accuracy

±1.5%RD (at 500 kPa, 23°C)

Conversion standard temperature : -10 to +60°C (In unit of 1°C)

: 0.00 to 10.00 kPa (In unit of 0.01 kPa, gauge pressure) Conversion standard pressure Atmospheric pressure under operating environment : 0.0 to 200.0 kPa

(In unit of 0.1 kPa, absolute pressure)

Low flow cutoff In case the measurement flow is lower than Qcut, 0 m²/h is displayed for instantaneous flow

Qcut (can be changed by button operation and communication)

Model	UZ40	UZ50
Initial setting value	+0.3	+0.6

Unit: Correlated to unit of sub display value

Response-ability	Instantaneous flow display value Pressure display value Temperature display value	 0.5 second (smoothing by moving average method (initial setting value: 4 times)) 0.5 second (smoothing by moving average method (initial setting value: 10 times)) 0.5 second
	remperature display value	0.0 300010

"O" are selectable items.

[m³/h]



2/4

Display Main display : The following is switched and selected using the "left button". Accumulated flow volume (m³)·Trip accumulated flow volume (m³) Sub display : The following is switched and selected using the "right button". Conversion flow type Instantaneous flow (m³/h)·Pressure (kPaG)·Temperature (°C) Actual flow type Instantaneous flow (m³/h)·working gas pressure setting value (kPaG)·Temperature (°C)

Number of digits displayed

Main display

Forward accumulated flow volume [m ³]	:	0000000.0*	9 digits
Forward trip accumulated flow volume [m ³]	:	ト 0000000.0*	8 digits
Unit: Selected by button operation and comm	unic	ation	

Se	elected by button operat	tion and communication	
	When NORMAL flow is	When standard flow is	When actual flow
	selected	selected	is selected
	NORMAL m ³	Standard m ³	m ³

*When Actual flow display (m3) is selected, "Forward accumulated flow volume" and "Forward trip accumulated flow volume" are displayed with 2 decimal places.

Sub display

Instantaneous flow [m ³ /h]: 000.00 (less than 1000)	5 digits
0000.0 (1000 or more and less than 1000	0) 5 digits
00000 (10000 or more)	5 digits
Unit: Selected by button operation and communication	

1. 00									
	When NORMAL flow is	When standard flow is	When actual flow is						
	selected	selected	selected						
	NORMAL m ³ /h	Standard m ³ /h	m³/h						

Pressure [kPa]: 0000.0 (Type with pressure sensor)5 digits000.00 (Type without pressure sensor)5 digits

* In the type without pressure sensor, the working gas pressure setting value is displayed.

Temperature [°C]: 00.0

3 digits

Contact output Nch open drain output 2 channels

 Pulse output Nch open drain output 1 channel Pulse unit : 1000 L/P (initial setting value) (can be changed by button operation)
 (and be changed by button to a set t

(can be changed to 10, 100, 1000 and 10000 L/P)

Maximum load: 26.4 VDC·50 mADuty: 20 to 80%Saturated voltage when ON: 1.5 V or lessCurrent when OFF: 50 μA or lessMaximum frequency: 10 Hz

Aichi tokei denki co., Itd.



Ver. 9

Model

Alarm output Nch open drain output 1 channel

Accumulated value upper limit alarm and flow upper or lower limit alarm (either one is selected by button operation)

Accumulated value upper limit alarm

When the accumulated flow volume for 1 h becomes higher than the set accumulated flow upper limit volume, an alarm signal is output.

(The accumulated flow volume upper limit value can be set by communication.)

*The 1 h measurement is started when the power supply is turned on.

Flow upper and lower limit alarm output

When the instantaneous flow becomes higher or lower than the set flow, an alarm signal is output.

(The alarm output upper and lower limit flow and alarm judgment value hysteresis width can be set by button operation.)

Current output Output method : 4 to 20 mA Discharge meothod

Output accuracy : ±0.1 mA (flow measurement accuracy, temperature measurement accuracy and pressure measurement accuracy are excluded)

: 400 Ω or less External load

("Instantaneous flow", "Pressure" and "Temperature" can be switched by a button operation and communication.)

When instantaneous flow is selected

[Forward flow display mode]

Zero output current : 4.0 mA (reverse flow to low flow cutoff)

Output current lower limit : 4.0 mA (clip at 4.0 mA) Output current upper limit : 22.0 mA (clip at 22.0 mA)

Full scale flow (can be changed by button operation and communication)

	Conversion flow type		Actual flow type	
Model	UZ40	UZ50	UZ40	UZ50
Initial setting value	300	600	80	150

Unit: Correlated to unit of sub display value

		: 4.0 mA: -10°C, 20.0 mA: output as +60°C (fixed) : 2.0 mA (clip at 2.0 mA) : 22.0 mA (clip at 22.0 mA)
Syncl Bit cc Bit tra Error *For t	nunication speed : 48 nronization method : As onfiguration : 8 b ansmission order : Or control : CR	oits, no parity, stop bit length 1 bit der from b0 to b7 (low order prioritized sending) CC on specifications, download the communication



Ultrasonic Flow Meter for Fuel Gas (External Power Supply 100 VAC Type) Ver. 9

4/4

[Nominal diamete	r] /	/ [Pressure]	AC
/ [Flow direction]	/	[Gas type]	

Measurable fluid	City gas (13A), butane (butane 70%, propane 30%), propane (propane 98%, butane 2%), nitrogen, argon					
Working fluid temperature	-10 to +60°C					
Working pressure	0 to 500 kPa (gauge pressure)					
Working ambient temperature	-10 to +60°C 90%RH or less (there must be no condensation)					
Storage ambient temperature	-20 to +70°C 90%RH or less (there must be no condensation)					
Power supply	100 VAC (85 to 115 VAC, 50/60 Hz) Power consumption: 10 W or less					
Protection structure	IP 64 (JIS C0920: dust-proof, splash-proof type) which can be installed outdoors					
Flow direction	Free in upward, downward, left to right, and right to left (direction indicated by arrow is forward flow)					
Installation position	Horizontal or vertical (cannot be installed with the position that the display portion faces downward or the cable introduction portion faces upward)					
Pressure drop	500 Pa or less (air, standard atmospheric pressure, at maximum flow)					
Mass	Model	UZ40	UZ50			
	Mass	7.0 kg	8.8 kg			
Material	 Measurement portion:Engineering plastic (PPS etc.) Outer casing:Stainless alloy Sensor rubber : FVMQ (Fluoro silicone rubber) Display potion casing :Aluminum alloy *O symbol indicates the gas contacting parts. 					
Standard working period	10 years (at ambient temperature of 20°C and ambient humidity of 65%RH) *10 years is not the warranty period.					
Accessories	M4 Hexagonal wrench ,sunshade cover (Optional Accessories)					
Others	RoHS Directive compliant					

2. Precautions in handling

- 2-1. Installation environment
 - (1) Although the high weather-proof electronic display is adopted, in case of installation at a place subjected to direct sunlight, provide a sunshade.
 - (2) Do not install the flow meter at a place with much electromagnetic noise, in corrosive atmosphere, or with high humidity liable to cause dew condensation
 - (3) This product is designed for outdoor installation, but avoid areas where there is a risk of water submergence and water always splashes.
 - (4) The GND (signal ground) is connected to the casing. Take the following measures, as necessary.
 - For DC24V type, use an insulation type power supply.
 - · Install a pulse isolator to isolate signals between the flow meter and a receiver.
 - Use an insulating bolt, insulating washer, etc., to isolate the casing and pipes.
 - (5) The meters do not conform to ATEX (explosion-proof) directive (2014/34/EU).

2-2. Piping conditions

- In case propane or butane is the fluid to be flown, make sure to use the flow meter under conditions that the fluid does not become oil mist state due to re-liquefaction, etc.
- (2) Even though the meter is installed indoor, it cannot be installed with the position that the display portion faces downward or the cable introduction portion faces upward.
- (3) When installing it at the upstream or downstream of the governor, install it 10D or more away from the governor.